



SPOT

LS.01.160.OR0.FI







Carry out the finish of the ceiling being careful to

keep the spotlight housing perfectly clean

ATTENTION: Before starting all electrical connections, make sure that the power supply is not powered. If this simply rule is not respected, the lighting source will be irremediably damaged.



Drill the hole 50mmdiameter for the

formwork compartment

Compliant with European standards (EMC, RoHs, Ecodesign and requirements specified

MC, RoHs, Ecodesign and requirements specif in the Low Voltage Directive (LVD) CLASS III
Operating with SELV

Insert the formwork and fix it to the drywall

with two screws

POWER SUPPLY

By remote power supply SELV OUTPUT 350mA constant current. For 350mA RGB please see the pilot module power supply.



Separate waste collection of electric and electronic

Carry out the electrical connection respecting

the polarity. Insert in position the spotlight

Made in Italy ed, manufactured and as

Projected, manufactured and assembled in Italy

Final result